



Your Starter Kit Includes:

4
ITEMS

3 Decorative Ornaments
1 Reversible Background
510mm wide x 300mm high

3016 | 1
Bamboo garden
4 piece starter kit



Your Starter Kit Includes:

4
ITEMS

3 Decorative Ornaments
1 Reversible Background
510mm wide x 300mm high

3017 | 1
Bonsai garden
4 piece starter kit